


Thingspeak : génération des clés

1 - Choisir le canal à visualiser :



2 - Les clés sont générées automatiquement :

Recyclage Piles

Channel ID: 1141020
Author: mwa0000018749664
Access: Public

Channel Description: Communiquer en WIFI l'état de remplissage d'un bac de recyclage de piles

Private View | Public View | Channel Settings | Sharing | **API Keys** | Data Import / Export

Write API Key

Key: **5J8HJUC0T7YU4P**

[Generate New Write API Key](#)

Read API Keys

Key: **2XNHUJUC0L0U1**

Help

API keys enable you to write data to a channel or read data from a private channel. API keys are auto-generated when you create a new channel.

API Keys Settings

- Write API Key:** Use this key to write data to a channel. If you feel your key has been compromised, click **Generate New Write API Key**.
- Read API Key:** Use this key to allow other people to view your private channel feeds and charts. Click **Generate New Read API Key** to generate a new read key for the channel.
- Note:** Use this field to enter information about channel read keys. For example, add notes to keep track of users with access to your channel.

API Requests

[Write a Channel Feed](#)

This website uses cookies to improve your user experience, personalize content and ads, and analyze website traffic. By continuing to use this website, you consent to our use of cookies. Please see our [Privacy Policy](#) to learn more about cookies and how to change your settings.

3 - Copiez les clés et collez-les dans le programme à mettre en liaison.